



USER INSTRUCTIONS for SERVERY AREA WATER HEATER

1. The filling and heating cycles of the Sadia Supreme 155 are completely automatic.
2. To dispense water, a suitable container having been placed under the outlet spout, the tap handle should be pulled down and towards (or pushed away from) the user. The water dispensed will at all times be boiling or close to boiling point so due caution must be taken when using the product, especially if it is likely to be used by children, aged or infirm persons.
3. The tap handle is spring loaded so that when released it will spring back to the “off” position (no flow).
4. The Supreme is fitted with four indicators to give a visual indication of the unit’s status.

| | |
|--|--|
| ON Indicator | Will be illuminated as long as the electrical supply to the Supreme is switched on |
| TEMPERATURE READY Indicator | When illuminated indicates that the stored water is hot enough to use |
| HALF FULL Indicator | When illuminated indicates that the unit is at least half full of hot water |
| FULL Indicator | When illuminated indicates that the unit is at its full capacity |

5. If the store of hot water is completely withdrawn, the flowrate from the outlet tap will reduce to the filling rate of the heater. This slow flowrate allows the incoming water to be instantly reheated, it does not indicate a fault with the water heater.
6. If the Supreme is not used for a few days the water may become “stale”. In these instances it is advisable to draw off the contents and discard the water at least twice to remove the “stale” water. This will ensure that “freshly” boiled water is used to make your drinks etc.
7. Similarly, if left unused it is possible that some scale residue will collect in the outlet tap. This will cause the outlet water to appear “milky” for a short while. If this condition occurs it is recommended that the first few cups are drawn off and discarded